

Cab Rack Installation Instructions


Required tools for installation:

Drill with $\frac{3}{8}$ inch and $\frac{3}{16}$ inch drill bits
 $\frac{3}{8}$ " Nut driver
 $\frac{3}{16}$ " Combo Wrench
 $\frac{3}{16}$ " Deep Well Socket and Ratchet




Required Hardware for Installation (not supplied):

(4) $\frac{3}{8}$ inch x $1\frac{1}{2}$ inch bolts, washers and nuts
(4) #10 sheet metal screws



- 1) Set the Cab Rack in position on truck. Make sure it is centered from side to side and the correct distance from the truck cab.
- 2) Find 4 locations to drill through the cab rack feet and the truck bed rail. These should be unobstructed and in the approximate locations shown.
- 3) Drill 4 x $\frac{3}{8}$ " holes in the selected locations.
- 4) Secure the Cab Rack using the $\frac{3}{8}$ inch bolts, washers and screws.
- 5) Drill 4 x $\frac{3}{16}$ " holes in the diamond face plate and front bed rail.
- 6) Install the 4 #10 sheet metal screws.



NOTES

Do not run this vehicle through automated car washes if optional items or accessories are attached to the cab rack. Failure to follow these instructions voids product warranty and damage to the vehicle, cab rack or persons may result.

This cab rack is not intended to serve as a roll bar and does not offer any crash protection. No fitness for this use is expressed or implied.

Cargo carrying capacity is 250 pounds. Any load must be secured to the vehicle bed. Bed reinforcement may be required. Refer to the vehicle manufacturing recommendations for attaching accessories to the pickup bed.

2 Year warranty is VOID if the customer fails to install the Cab Rack as per mounting instructions supplied by ProTech.